How to use our Kayak Carts

- These kayak carts are meant to assist you in moving the kayak to and from the CT River. You may not take the kayak to any other location.
- All three carts are the same, and all will work with any of our kayaks.
- You are welcome to borrow a bike lock from the closet so you may safely leave the cart near the boat launch. Otherwise, you are welcome to bring the cart with you on the kayak or return it to the storage closet.
- Scan this QR Code to watch a video on how to attach the carts:




1. Set up the kayak cart next to the kayak, towards the front of the kayak. Please use the kickstand to keep the cart steady as you move the kayak on to it.






2. Lift the front of the boat and place it on top of the cart, with the center of the kayak on the center of the cart.



3. Tie the black strap to the frame of the kayak cart.



4. Wrap the long black strap around the kayak. Feed the strap through the eyelets/fittings on top of the kayak for extra support. Tighten the strap as much as possible by feeding the open end of the strap through the buckle.



5. When you are ready to move the kayak, pull it from the back (the opposite end from where the cart is affixed.